

Ladies Bag User Manual

I. Product Overview

This ladies bag is for daily use, stylish and practical for storage. Suitable for work, shopping, dating and travel, it organizes items neatly and adds elegance.

II. Product Usage Instructions & Restrictions

2.1 Correct Usage Methods

1. Opening & Closing: Zippers: Pull the slider gently along the track; avoid force to prevent jamming or damage.
2. Magnetic snaps: Align and press to fasten; pull apart slowly to protect magnetism.
3. Buckles: Insert the pin into the hole to fasten; press release to open.

2.2 Usage Restrictions

- Avoid prolonged direct sunlight to prevent fading, discoloration or cracking (especially leather).
- Keep away from water, oil and ink; clean immediately if contaminated.
- Do not scratch with sharp tools or rub against rough surfaces.
- Not for children under 3; avoid ingestion or injury from small parts.

III. Daily Maintenance Tips

- Leather/Faux Leather: Wipe with a soft dry cloth regularly; use professional cleaner for stains. Store with paper to retain shape in a cool, dry place.
- Canvas/Nylon: Hand-wash with mild detergent; air-dry naturally, no machine wash or sunlight.
- Zippers: Apply a little wax/lubricant if stuck for smooth use.

IV. Warning/Safety Information

⚠ Warning

1. Keep small parts away from children under 3; seek medical help immediately if ingested.
2. Do not hang overloaded bags for long to avoid muscle soreness or injury.
3. Keep the bag closed and close to your body in crowds to prevent theft and scratches.